

## **QAQC Powder Lance**

The Powder Lance can be used to take large volume samples of cohesive powders. The sampler can be used horizontally through a sack or else it can be used vertically.

- Cross sectional sampler
- 316 stainless steel
- Suitable for sticky cohesive powders

## Operation

- Insert the sampler into the product. 1.
- Rotate the sampler through 360°. The scraper forces the 2. powder in to the sampler along the length of the slot.
- Remove the sampler.
- Unscrew the tip of the sampler.
  Push the Sample Ejection Rod into the Powder Lance to push out the sample







Stock No.	Sampler Length	Slot Length	Max Sample Volume
675 2250A600	630mm	540mm	190ml
675 2250A1000	1030mm	930mm	300ml
675 2250A2000	2030mm	1500mm	520ml

675 8570A700	Sample Ejection Rod - 316 stainless steel - 700mm length
675 8570A1100	Sample Ejection Rod - 316 stainless steel - 1100mm length

Cleaning Brushes - see page 129

Sampler Cases - see page 130

XRF Certification - see page 139

675 TIP2 Round tip (sampler supplied as standard with pointed tip)

**QUICK QUOTE** 

**ONLINE PRICING** 



The disposable Powder Lance is ideal for taking a cross sectional sample through a bulk powder.

- Assembled & Packed in a Cleanroom
- Individually Bagged FDA & EU 10/2011 Conforming Materials
- BSE/TSE Free
- Full Batch Traceability
- ATEX Rated
- Available Sterile (gamma irradiated)





Without End Tip - ideal for use with sticky, cohesive powders



The disposable Powder Lance is quick and easy to use:

- Push the disposable Powder Lance into the product, rotate the sampler and then withdraw
- Deposit the sample into a suitable container
- Place the used sampler into its plastic bag

	End	

Stock No.	Pre-Sterile	Blade Lengt	n Overall Length	Volume	Materia	I Per Box
675 8063H300	No	300mm	400mm	75ml	HDPE	20
675 8063H300S	Yes	300mm	400mm	75ml	HDPE	20
675 8063H500	No	500mm	600mm	125ml	HDPE	20
675 8063H500S	Yes	500mm	600mm	125ml	HDPE	20
675 8063H1000	No	850mm	950mm	200ml	HDPE	20
6758063H1000S	Yes	850mm	950mm	200ml	HDPE	20

**ONLINE PRICING QUICK QUOTE**